






MONTAGE-ANLEITUNGEN
 INSTRUCTIONS DE MONTAGE
 ISTRUZIONI PER IL MONTAGGIO
 MOUNTING INSTRUCTIONS

Raumkonsole zu «Kleine Leine»
 Console murale court
 Consolle a parete corta
 Short wall bracket




Decken-Teleskopkonsole
 Console télescopique au plafond
 Consolle telescopica al soffitto
 Telescopic ceiling bracket




Klapptisch
 Table pliante «Swing»
 Tavolo ribaltabile «Swing»
 Folding table «Swing»

Wandschiene
 Barre
 Binario
 Wall bar




Raumkonsole

Console murale
Consolle a parete
Wall bracket




Decken-Teleskopträger

Support télescopique au plafond
Supporto telescopica al soffitto
Telescopic ceiling bracket




Wandschiene

Rail mural
Binario a parete
Wall bar




Wandschiene mit Wandkonsole

Rail mural avec console murale
Binario a parete con supporto a parete
Wall bar with wall bracket



Schiennenverbinder

Connecteur de rail
Connettore a binario
Wall bar connector



Klapptisch

Table pliante «Swing»

Tavolo pieghevole «Swing»

Foldable table «Swing»

